

# Information and Instructions

This individual shop manual is one unit of a series on wheel type tractors. Contained in it are the necessary specifications and the brief but terse procedural data needed by a mechanic when repairing a tractor on which he has had no previous actual experience.

The material is arranged in a systematic order beginning with an index which is followed immediately by a Table of Condensed Service Specifications. These specifications include dimensions, fits, clearances and timing instructions. Next in order of arrangement is the procedures paragraphs.

In the procedures paragraphs, the order of presentation starts with the front axle system and steering and proceeding toward the rear axle. The last paragraphs are devoted to the power take-off and power lift systems. Interpersed where needed are additional tabular specifications pertaining to wear limits, torquing, etc.

## HOW TO USE THE INDEX

Suppose you want to know the procedure for R&R (remove and reinstall) of the engine camshaft. Your first step is to look in the index under the main heading of ENGINE until you find the entry "Camshaft." Now read to the right where under the column covering the tractor you are repairing, you will find a number which indicates the beginning paragraph pertaining to the camshaft. To locate this wanted paragraph in the manual, turn the pages until the running index appearing on the top outside corner of each page contains the number you are seeking. In this paragraph you will find the information concerning the removal of the camshaft.

# SHOP MANUAL

# JOHN DEERE

SERIES  
2840 — 2940 — 2950

Tractor serial number is stamped in right side of front support and is also located on a plate attached to right side of front support. Engine serial number is stamped on a plate on right side of engine cylinder block.

## INDEX (By Starting Paragraph)

	2840	2940	2950		2840	2940	2950
<b>BRAKES</b>				<b>ENGINE (Cont.)</b>			
Bleed and Adjust . . . . .	149	149	149	Cylinder Sleeves . . . . .	62,	62,	62,
Brake Test . . . . .	151	151	151		63	63	63
R&R and Overhaul . . . . .	152	152	152	Engine Removal . . . . .	47	47	47
				Flywheel . . . . .	68	68	68
<b>CLUTCH</b>				Front Oil Seal . . . . .	54	54	54
Bleed System . . . . .	...	99	99	Main Bearings . . . . .	66	66	66
Clutch Cylinders . . . . .	...	100	100	Oil Pump and			
Pedal Adjustment . . . . .	97	97,	97,	Relief Valve . . . . .	70	70	70
		98	98	Piston and Sleeves . . . . .	62	62	62
R&R and Overhaul . . . . .	102	102,	103	Piston Pins			
		103		and Bushings . . . . .	64	64	64
Tractor Split . . . . .	101	101	101	Piston Rings . . . . .	62	62	62
				Rear Oil Seal . . . . .	67	67	67
<b>CREEPER TRANSMISSION</b>				Rocker Arms . . . . .	52	52	52
Operation . . . . .	...	...	116	Rod & Piston Units . . . . .	61	61	61
R&R and Overhaul . . . . .	...	...	118	Timing Gear Cover . . . . .	54	54	54
Trouble-Shooting . . . . .	...	...	117	Timing Gears . . . . .	55	55	55
				Valve Clearance . . . . .	50	50	50
<b>COOLING SYSTEM</b>				Valve Guides . . . . .	51	51	51
Radiator . . . . .	89	89	89	Valves and Seats . . . . .	49	49	49
Water Pump . . . . .	90	90	90	Valve Springs . . . . .	51	51	51
<b>DIFFERENTIAL</b>				<b>FINAL DRIVE</b>			
Bevel Gears . . . . .	135	143	143	Overhaul . . . . .	140	148	148
Overhaul . . . . .	134	142	142	Remove and Reinstall . . .	139	147	147
Remove and Reinstall . . .	133	141	141				
				<b>FRONT SYSTEM</b>			
<b>ELECTRICAL SYSTEM</b>				<b>(TWO-WHEEL DRIVE)</b>			
Alternator				Axle Center Member . . .	1	1	1
and Regulator . . . . .	94	94	94	Spindles and Bushings . .	3	3	3
Starter Motor . . . . .	96	96	96	Tie Rods and Toe-in . . . .	4	4	4
				Wheel Bearings . . . . .	2	2	2
<b>ENGINE</b>							
Cam Followers . . . . .	53	53	53	<b>FRONT-WHEEL DRIVE</b>			
Camshaft . . . . .	56	56	56	Differential Unit . . . . .	...	12	22
Connecting Rod				Drive Clutch . . . . .	...	13	23
Bearings . . . . .	65	65	65	Drive Shaft . . . . .	...	7	18
Crankshaft . . . . .	66	66	66	Front Drive Axle . . . . .	...	8	19
Cylinder Head . . . . .	48	48	48	Solenoid . . . . .	...	15	25

# INDEX (CONT.)

	2840	2940	2950		2840	2940	2950
<b>FRONT-WHEEL DRIVE (Cont.)</b>				<b>POWER STEERING</b>			
Steering Knuckle				Pressure Control Valve ..	29	38	38
Housing . . . . .	...	11	21	Pressure Reduction			
Tie Rod and Toe-in . . . . .	...	6	17	Valve . . . . .	...	40	...
Trouble-Shooting . . . . .	...	5	16	Safety Valve Block . . . . .	...	37	37
Wheel Hub				Steering Cross Shaft . . . . .	31	...	...
and Planetary . . . . .	...	9	20	Steering Cylinders . . . . .	28	42,	43,
						43,	45,
						44,	46
						45	
				Steering Valve . . . . .	27	33	33
				Trouble-Shooting . . . . .	26	32	32
<b>FUEL SYSTEM</b>				<b>POWER TAKE-OFF</b>			
Bleed System . . . . .	77	77	77	Operation . . . . .	155	160	160
Filter . . . . .	76	76	76	Pressure Test . . . . .	156	161	161
Fuel Lift Pump . . . . .	74	74	74	R&R and Overhaul . . . . .	157	162	162
Injection Pump . . . . .	86	86	86				
Injector Nozzles . . . . .	78	78	78	<b>REMOTE CONTROL SYSTEM</b>			
Speed Adjustment . . . . .	88	88	88	Breakaway Coupler . . . . .	183	183,	184
Timing . . . . .	59,	59,	59,			184	
	87	87	87	Remote Cylinder . . . . .	185	185	185
Water Trap . . . . .	...	...	75	Selective Control Valve . .	182	182	182
<b>HAND BRAKE</b>				<b>SOUND GARD BODY</b>			
R&R and Overhaul . . . . .	...	154	154	Remove and Reinstall . . . . .	...	186	186
<b>HI-LO SHIFT</b>				<b>TRANSMISSION</b>			
Testing . . . . .	107	112,	112,	Operation . . . . .	119	126	126
		113	113	Shafts and Gears . . . . .	123	130	130
Operation . . . . .	106	110	110	Shifter Shafts			
Overhaul . . . . .	108,	114,	114,	and Forks . . . . .	122	128,	128,
	109	115	115			129	129
				Top Cover . . . . .	120	128	128
				Tractor Split . . . . .	121	127	127
				Transmission Oil Pump . .	124	131	131
<b>HYDRAULIC LIFT SYSTEM</b>							
Hydraulic Pump . . . . .	175	175	175				
Load Control . . . . .	179	179	179				
Rockshaft Housing . . . . .	177	177	177				
System Adjustments . . . . .	170	170	170				
System Tests . . . . .	166	166	166				
Trouble-Shooting . . . . .	165	165	165				

## DUAL DIMENSIONS

This service manual provides specifications in both the Metric (SI) and U.S. Customary systems of measurement. The first specification is given in the measuring system used during manufacture, while the second specification (given in parenthesis) is the converted measurement. For instance, a specification of "0.28 mm (0.011 inch)" would indicate that the equipment was manufactured using the metric system of measurement and the U.S. equivalent of 0.28 mm is 0.011 inch.