# **Information and Instructions**

This individual shop manual is one unit of a series on wheel type tractors. Contained in it are the necessary specifications and the brief but terse procedural data needed by a mechanic when repairing a tractor on which he has had no previous actual experience.

The material is arranged in a systematic order beginning with an index which is followed immediately by a Table of Condensed Service Specifications. These specifications include dimensions, fits, clearances and timing instructions. Next in order of arrangement is the procedures paragraphs.

In the procedures paragraphs, the order of presentation starts with the front axle system and steering and proceeding toward the rear axle. The last paragraphs are devoted to the power take-off and power lift systems. Interspersed where needed are additional tabular specifications pertaining to wear limits, torquing, etc.

## HOW TO USE THE INDEX

Suppose you want to know the procedure for R&R (remove and reinstall) of the engine camshaft. Your first step is to look in the index under the main heading of ENGINE until you find the entry "Camshaft." Now read to the right where under the column covering the tractor you are repairing, you will find a number which indicates the beginning paragraph pertaining to the camshaft. To locate this wanted paragraph in the manual, turn the pages until the running index appearing on the top outside corner of each page contains the number you are seeking. In this paragraph you will find the information concerning the removal of the camshaft.

# SHOP MANUAL

MODELS 655, 755, 756, 855, 856 and 955

The 13 digit product identification (serial) number is on a plate (Fig. 1) located below the rear pto shaft. The engine serial number plate (Fig. 2) is attached to top of rocker arm cover.



Fig. 1—The tractor serial number plate is located just below rear pto output shaft.



Fig. 2—Engine model and serial numbers are located on plate attached to top of rocker arm cover.

# **INDEX (By Starting Paragraph)**

	Models
	655, 755, 756
85	55, 856 and 955
COOLING SYSTEM	
Radiator	
Thermostat.	
Water Pump	
DIESEL FUEL SYSTEM	
Fuel Filters and Lines	81
Governor and Injection Pump Cams	haft 88 & 90
Injection Pump	
Injector Nozzles	
Preheater/Glow Plugs	96
DIFFERENTIAL	
Differential and Bevel Gears	
Differential Lock and Shifter	122
ELECTRICAL SYSTEM	
Alternator and Regulator	100
Circuit Description	107
Chedie Debeription	

Safety Switches ..... 106 Starter ..... 103

855	655,	755, and	756 955
ENGINE	,000	anu	
(MODELS 655, 755 AND 756)			
Cam Followers			30
Camshaft			38
Connecting Rod and Bearings			42
Crankshaft and Main Bearings			43
Crankshaft Front Oil Seal			44
Crankshaft Rear Oil Seal			45
Cylinder Head			25
Engine to Transmission Drive Shaft .			24
Flywheel			46
Maintenance			. 19
Oil Pan			47
Oil Pump and Pressure Relief Valve .			48
Piston, Rings and Cylinder			40
Piston Pin			. 41
R & R Engine Assembly			23
Rocker Arms and Push Rods			. 29
Rod and Piston Units			. 39
Timing Gear Cover and			
Crankshaft Front Oil Seal			. 36

Illustrations for Fig. 1 and Fig. 2 reproduced by permission of Deere & Company. Copyright Deere & Company.

**Models** 

## Models 655, 755, 756 855, 856 and 955

## ENGINE

## (MODELS 655, 755 AND 756) (Cont.)

Timing Gear Housing	37
Timing Gears	31
Valve Clearance	26
Valve Springs	<b>28</b>
Valves, Guides and Seats	27

#### ENGINE

## **MODELS 855, 856 AND 955**

Cam Followers	61
Camshaft	69
Connecting Rod and Bearings	73
Crankshaft and Main Bearings	74
Crankshaft Front Oil Seal	75
Crankshaft Rear Oil Seal	76
Cylinder Head	56
Engine to Transmission Drive Shaft	55
Flywheel	77
Maintenance	50
Oil Pan	78
Oil Pump and Pressure Relief Valve	79
Piston, Rings and Cylinder	71
Piston Pin.	72
R & R Engine Assembly	54
Rocker Arms and Push Rods	60
Rod and Piston Units	70
Timing Gear Cover and	
Crankshaft Front Oil Seal	67
Timing Gear Housing	<b>6</b> 8
Timing Gears	62
Valve Clearance	57
Valve Springs	59
Valves, Guides and Seats	58
Crankshaft Front Oil Seal Timing Gears Housing Valve Clearance Valve Springs Valves, Guides and Seats	67 68 62 57 59 58

## FRONT AXLE SYSTEM

(FOUL-WHEEL DRIVE)	
Differential	16
Differential Input	15
Front Axle Assembly and Steering Linkage	11
Front Drive Spindle	14

		Moo	dels
(	655,	755,	756
855,	856	and	955



#### FRONT AXLE SYSTEM (FOUR-WHEEL DRIVE) (Cont.)

(	
Front Final Drive	13
Front Wheel Drive Gear Case	17

## FRONT AXLE SYSTEM

(TWO-WHEEL DRIVE)

Front Axle Assembly and Steering Linkage..... 1

Maintenance ..... 10

## HYDRAULIC LIFT SYSTEM

Cylinder Cover and Piston	153
Flow Divider and Selective Control Valves	147
Hydraulic Pump	144
Relief Valves	150
Rockshaft and Housing	145
Rockshaft Control Valve	152
Tests and Adjustments	138
Trouble Shooting	137

## **POWER TAKE OFF**

Clutch and Drive Shafts	134
Control Valves	133
Mid Pto	135
Pto Inertia Brake	132
Rear Output Shaft	131
Tests and Adjustments	129

## **REAR AXLE, FINAL DRIVE AND BRAKES**

Brakes		 	 	126
Rear Axle and	l Final Drive.	 	 	124

## **STEERING SYSTEM**

Steering Control Valve	•		 					•				6
Steering Cylinder			 									8

## TRANSMISSION

Charge Pump	115
Hydrostatic Unit	116
Lubrication	109
Range Transmission	118
Tests and Adjustments	111
Troubleshooting	110

# **DUAL DIMENSIONS**

This service manual provides specifications in both U.S. Customary and Metric (SI) systems of measurement. The first specification is given in the measuring system perceived by us to be the preferred system when servicing a particular component, while the second specification (given in parenthesis) is the converted measurement. For instance, a specification of 0.011 inch (0.28 mm) would indicate that we feel the preferred measurement in this instance is the U.S. Customary system of measurement and the Metric equivalent of 0.011 inch is 0.28 mm.





6