

Information and Instructions

This individual shop manual is one unit of a series on wheel type tractors. Contained in it are the necessary specifications and the brief but terse procedural data needed by a mechanic when repairing a tractor on which he has had no previous actual experience.

The material is arranged in a systematic order beginning with an index which is followed immediately by a Table of Condensed Service Specifications. These specifications include dimensions, fits, clearances and timing instructions. Next in order of arrangement is the procedures paragraphs.

In the procedures paragraphs, the order of presentation starts with the front axle system and steering and proceeding toward the rear axle. The last paragraphs are devoted to the power take-off and power lift systems. Interpersed where needed are additional tabular specifications pertaining to wear limits, torquing, etc.

HOW TO USE THE INDEX

Suppose you want to know the procedure for R&R (remove and reinstall) of the engine camshaft. Your first step is to look in the index under the main heading of ENGINE until you find the entry "Camshaft." Now read to the right where under the column covering the tractor you are repairing, you will find a number which indicates the beginning paragraph pertaining to the camshaft. To locate this wanted paragraph in the manual, turn the pages until the running index appearing on the top outside corner of each page contains the number you are seeking. In this paragraph you will find the information concerning the removal of the camshaft.

INDEX (By Starting Paragraph)

	Models 340, 350, 355, 360 and 399	Models 340, 350, 355, 360 and 399
BRAKES		
Adjustment –		
340 Models With Drum Brakes	253	
Models With Disc Brakes Before		
Serial Number V39466	254	
Models With Disc Brakes After		
Serial Number V39465	255	
Disc Brake Assembly –		
All Models With Disc Brakes	262	
Drum Brake Assembly		
340 Models With Drum Brakes	261	
Fluid and Bleeding	256	
Master Cylinders	257	
Slave Cylinders –		
340 Models With Drum Brakes	258	
Models With Disc Brakes Before		
Serial Number V39466	259	
Models With Disc Brakes After		
Serial Number V39465	260	
CLUTCH (ENGINE)		
Engine/Transmission Split	152	
Linkage Adjustment	151	
R&R and Overhaul–		
Models With Dual Clutch	153	
Models With Split Torque Clutch	155	
DIESEL FUEL SYSTEM		
Bleeding	133	
Filters	131	
Fuel Lift Pump	132	
Injection Pump Specifications	145	
Injector Nozzles	134	
Pump Drive Gear	144	
Pump Timing	142	
ELECTRICAL SYSTEM		
Alternator and Regulator	147	
Circuit Description	149	
Starter	148	
Wiring Diagrams	149	
ENGINE (Three-Cylinders)		
Cam Followers	41	
Camshaft	53	
Connecting Rods and Bearings	57	
Cooling System	64	
Crankshaft and Bearings	58	
Crankshaft Rear Oil Seal	59	
Cylinder Head	37	
Flywheel	60	
Front End/Engine Split	35	
ENGINE (Three-Cylinders) (Cont.)		
Oil Pan	61	
Oil Pump	62	
Piston Pins	56	
Pistons, Rings and Sleeves	55	
R & R Engine	36	
Relief Valve	63	
Rocker Arms	42	
Rod and Piston Units	54	
Timing Gear Cover	45	
Timing Gear Housing	52	
Timing Gears	46	
Valve Clearance	43	
Valve Guides	39	
Valve Springs	40	
Valve Timing	44	
Valves and Seats	38	
ENGINE (Six-Cylinder 6.3544)		
Accessory/Injection Pump Drive	81	
Cam Followers	73	
Camshaft	82	
Connecting Rods and Bearings	86	
Cooling System	93	
Crankshaft and Bearings	87	
Crankshaft Gear and Idler Gears	80	
Crankshaft Pulley	76	
Crankshaft Rear Oil Seal	88	
Cylinder Head	69	
Flywheel	89	
Front End/Engine Split	67	
Oil Pan	90	
Oil Pump	91	
Piston Pins	85	
Pistons, Rings and Sleeves	84	
R & R Engine	68	
Relief Valve	92	
Rocker Arms	74	
Rod and Piston Units	83	
Timing Gear Housing	79	
Timing Gears	77	
Valve Clearance	75	
Valve Guides	71	
Valve Springs	72	
Valves and Seats	70	
ENGINE (Six-Cylinder 1006.6)		
Cam Followers	102	
Camshaft	113	
Connecting Rods and Bearings	117	
Cooling System	124	
Crankshaft and Bearings	118	

Models
340, 350, 355,
360 and 399

ENGINE (Six-Cylinder 1006.6) (Cont.)

Crankshaft Pulley	105
Crankshaft Rear Oil Seal	119
Cylinder Head	98
Flywheel	120
Front End/Engine Split	96
Oil Pan	121
Oil Pump	122
Piston Pins	116
Pistons, Rings and Sleeves	115
R & R Engine	97
Relief Valve	123
Rocker Arms	103
Rod and Piston Units	114
Timing Gear Cover and Front Oil Seal	106
Timing Gear Housing	112
Timing Gears	108
Timing the Gears	107
Valve Clearance	104
Valve Guides	100
Valve Springs	101
Valves and Seats	99

FRONT AXLE SYSTEM (Two-Wheel-Drive Models)

Front Axle Assembly and Steering Linkage	1
--	---

FRONT-WHEEL DRIVE (Four-Wheel-Drive Models)

Differential -	
Except "Hydralock"	13
"Hydralock"	15
Drive Shaft	9
Front Drive Axle	10
Planetary Assembly	11
Steering Knuckle Housing and Wheel Hub	12
Track Rod and Toe-in	8
Tractor Split -	
Without Cab	17
With Cabs	18
Transfer Gearbox -	
Except Twelve-Speed Shuttle	19
With Twelve-Speed Shuttle Transmission	20

HYDRAULIC SYSTEM

Auxiliary Hydraulic Pump	293
Auxiliary Remote Control Valves	297
Auxiliary System Pressure	294
Hydraulic Lift Pump	290
Lift Cover	285
Reservoir and Filters	275
Selector Valve	287
Tests and Adjustments	277
Troubleshooting	276

Models
340, 350, 355,
360 and 399

INDEPENDENT POWER TAKE-OFF -

Hydraulic Pressure Tests	273
Left Side Cover and Control Valve	270
Output Shaft	269
Pto Clutch, Brake and Control Valve	271
Live Power Take-off	262

MAIN DRIVE BEVEL DRIVE GEARS AND DIFFERENTIAL

Differential and Bevel Ring Gear	235
Differential Lock	237
Main Drive Bevel Gears	240

POWER TAKE-OFF

Live	263
Independent	267

REAR AXLE AND FINAL DRIVE

Drive Axle -	
340 Models With Direct Drive Axle	251
Models With Planetary Final Drive	252
Rear Axle Assembly -	
Early 340 Models With Drum Brakes	242
340 Models With Disc Brakes	244
All Except 340 Models	246
Planetary Assembly -	
Models With Planetary Final Drive	247

STEERING SYSTEM

Filter and Bleeding	22
Power Cylinder -	
Two-Wheel-Drive With Three-Cylinder Engine	31
Two-Wheel-Drive With Six-Cylinder Engine	32
Four-Wheel-Drive Models	33
Pump -	
Models With Separate Pump	27
Models With Tandem Pump	29
Steering Control Valve	34
System Pressure -	
With Separate Steering Pump	24
With Tandem Pump	25
Troubleshooting	23

TRANSMISSION (Six-Speed Shuttle)

Countershaft (Layshaft) and Gears	204
Lubrication	194
Mainshaft (Output Shaft) and Gears	203
Planetary Unit	199
Pto Input Shaft and Retainer Housing	200
Pto Lower Shaft Front Bearing and Retainer	201
Reverse Idler Gear And Shaft	205
Shifter Rails and Forks	198

	Models 340, 350, 355, 360 and 399
TRANSMISSION (Six-Speed Shuttle) (Cont.)	
Top Cover	197
Tractor Rear Split	195
Transmission Input Shaft and Shuttle Gears	202
Transmission Removal	196

TRANSMISSION (Eight-Speed Shuttle)	
Countershaft (Layshaft) and Gears	216
Lubrication	206
Mainshaft (Output Shaft) and Gears	215
Planetary Unit	211
Pto Input Shaft and Retainer Housing	212
Pto Lower Shaft Front Bearing and Retainer	213
Reverse Idler Gear and Shaft	217
Shifter Rails and Forks	210
Top Cover	209
Tractor Rear Split	207
Transmission Input Shaft	214
Transmission Removal	208

TRANSMISSION (Eight-Speed Standard)	
Countershaft (Layshaft) and Gears	168
Lubrication	157
Mainshaft (Output Shaft) and Gears	167
Planetary Unit	163
Pto Input Shaft and Retainer Housing	164
Pto Lower Shaft Front Bearing and Retainer	165
Reverse Idler Gear and Shaft	169
Shifter Rails and Forks	162
Top Cover and Shift Levers	161
Tractor Rear Split	158
Transmission Input Shaft	166
Transmission Removal	160

TRANSMISSION (Eight-Speed Synchromesh)	
Countershaft (Layshaft) and Gears	180
Lubrication	170
Mainshaft (Output Shaft) and Gears	179
Planetary Unit	175
Pto Input Shaft and Retainer Housing	176
Pto Lower Shaft Front Bearing and Retainer	177
Reverse Idler Gear and Shaft	181
Shifter Rails and Forks	174

	Models 340, 350, 355, 360 and 399
TRANSMISSION (Eight-Speed Synchromesh) (Cont.)	
Top Cover	173
Tractor Rear Split	171
Transmission Input Shaft	178
Transmission Removal	172

TRANSMISSION (Twelve-Speed Shuttle)	
Forward/Reverse Shift Control Linkage	223
Lubrication	218
Main Gear Shift Lever and Selector Shaft	222
Main Transmission Countershaft and Gears	233
Main Transmission Input Shaft	231
Main Transmission Shift Rails and Forks	224
Main Transmission Upper Shaft and Gears	232
Pto Input Shaft and Retainer Housing	229
Pto Lower Shaft Front Bearing and Retainer	230
Range Change Lower Shaft	227
Range Change Unit Upper Shaft	225
Range Change Upper Shaft Bearing Preload	226
Range Selector Cam	228
Reverse Idler Gear and Shaft	234
Top Cover	221
Tractor Rear Split	219
Transmission Removal	220

TRANSMISSION (Twelve-Speed Synchromesh)	
Countershaft (Layshaft) and Gears	192
Lubrication	182
Mainshaft (Output Shaft) and Gears	191
Planetary Unit	187
Pto Input Shaft and Retainer Housing	188
Pto Lower Shaft Front Bearing and Retainer	189
Reverse Idler Gear and Shaft	193
Shifter Rails and Forks	186
Top Cover	185
Tractor Rear Split	183
Transmission Input Shaft	190
Transmission Removal	184

TURBOCHARGER (355 and 360 Models)	
Operation	128
Service	129