## **Information and Instructions**

This individual shop manual is one unit of a series on wheel type tractors. Contained in it are the necessary specifications and the brief but terse procedural data needed by a mechanic when repairing a tractor on which he has had no previous actual experience.

The material is arranged in a systematic order beginning with an index which is followed immediately by a Table of Condensed Service Specifications. These specifications include dimensions, fits, clearances and timing instructions. Next in order of arrangement is the procedures paragraphs.

In the procedures paragraphs, the order of presentation starts with the front axle system and steering and proceeding toward the rear axle. The last paragraphs are devoted to the power take-off and power lift systems. Interspersed where needed are additional tabular specifications pertaining to wear limits, torquing, etc.

#### HOW TO USE THE INDEX

Suppose you want to know the procedure for R&R (remove and reinstall) of the engine camshaft. Your first step is to look in the index under the main heading of ENGINE until you find the entry "Camshaft." Now read to the right where under the column covering the tractor you are repairing, you will find a number which indicates the beginning paragraph pertaining to the camshaft. To locate this wanted paragraph in the manual, turn the pages until the running index appearing on the top outside corner of each page contains the number you are seeking. In this paragraph you will find the information concerning the removal of the camshaft.

# SHOP MANUAL

#### MODELS 1250-1450-1650

Tractor serial number is located on a plate attached to rear of differential housing directly below pto output shaft. Engine model number and serial number are located on left side of engine.

## **INDEX (By Starting Paragraph)**

	1250	Models 1450	1650
BRAKES	01	01	81
Brake Piston and Disc	81	81	81 80
Brake Valve	80	80	
Park Brake	82	82	82
CLUTCH			
Clutch Unit	60	62	62
Clutch Shaft and Snubber Brake	64	64	64
COOLING SYSTEM			
Fan and Belt.	53	53	53
Radiator	52	52	52
Water Pump and Thermostat	54	54	54
DIESEL FUEL SYSTEM			
Fuel Filters and Bleeding	40	40	40
Fuel Supply Dymp	44	44	44
Fuel Supply Pump Injection Pump	41	41	41
Injection Pump	45	45	45
Injection Nozzles	40	40	10
DIFFERENTIAL AND BEVEL GEARS	72	72	72
ELECTRICAL SYSTEM			
Alternator and Regulator	55	55	55
Starter	57	57	57
ENGINE			
Cam Followers	22	22	22
Camshaft and Bushings	${26}$	$\overline{26}$	26
Clutch Split	$14^{-14}$	14	14
Connecting Rods and Bearings	30	30	30
Crankshaft Balancer		31	31
Crankshaft and Main Bearings	32	32	32
Crankshaft Oil Seals	33	33	33
Cylinder Head	16	16	16
Flywheel	34	34	34
F ly wheel	13	13	13
Front Split		37	37
Oil Cooler and Relief Valve	35	35	35
Oil Pressure Regulating Valve	35 36	36	36
Oil Pump			30 38
Piston Cooling Jets		 29	38 29
Piston Pins	29	29 28	$\frac{29}{28}$
Pistons, Sleeves and Rings	28		$\frac{28}{15}$
Remove and Reinstall Engine	15	15	
Rocker Arms and Push Rods	18	$\frac{18}{27}$	$\frac{18}{27}$
Rod and Piston Units	27	21	41

## **INDEX (CONT.)**

		Models		
	1250	1450	1650	
ENGINE (CONT.)				
Timing Gear Cover	24	24	24	
Timing Gears	$\frac{1}{25}$	$\overline{25}$	25	
Valve Clearance	$\overline{17}$	17	17	
Valve Guides	20	20	20	
Valve Springs	21	21	21	
Valve Timing	23	23	23	
Valves and Seats	19	19	19	
FINAL DRIVE	75	75	75	
FRONT AXLE				
Two Wheel Drive	1	1	1	
Front Wheel Drive	3	3	3	
HYDRAULIC LIFT SYSTEM				
Draft Sensing Springs	106	107	107	
Fluid and Filter	89	89	89	
Hydraulic Pump	96	96	96	
Lift Links	109	109	$109_{-5}$	
Linkage Adjustment	95	95	95	
Rockshaft Housing	97	97	97	
Rockshaft Piston, Cylinder and Cover	105	105	105	
Test and Adjust	91	91	91 00	
Troubleshooting	90	90	90	
Valves	101	101	101	
POWER STEERING				
Steering Bellcrank		12	12	
Steering Gear	10	10	10	
Steering Pump	11	11	11	
Test and Adjust	9	9	9	
POWER TAKE OFF				
Clutch Linkage and Release Bearing		85	85	
Output Shaft	87	88	88	
Shift Linkage	84	••••	•••••	
TRANSMISSION	65	65	65	
TURBOCHARGER		•••••	49	

## **DUAL DIMENSIONS**

This service manual provides specifications in both the Metric (SI) and U.S. Customary systems of measurement. The first specification is given in the measuring system used during manufacture, while the second specification (given in parenthesis) is the converted measurement. For instance, a specification of "0.28 mm (0.011 inch)" would indicate that the equipment was manufactured using the metric system of measurement and the U.S. equivalent of 0.28 mm is 0.011 inch.