

Information and Instructions

This individual shop manual is one unit of a series on wheel type tractors. Contained in it are the necessary specifications and the brief but terse procedural data needed by a mechanic when repairing a tractor on which he has had no previous actual experience.

The material is arranged in a systematic order beginning with an index which is followed immediately by a Table of Condensed Service Specifications. These specifications include dimensions, fits, clearances and timing instructions. Next in order of arrangement is the procedures paragraphs.

In the procedures paragraphs, the order of presentation starts with the front axle system and steering and proceeding toward the rear axle. The last paragraphs are devoted to the power take-off and power lift systems. Interspersed where needed are additional tabular specifications pertaining to wear limits, torquing, etc.

HOW TO USE THE INDEX

Suppose you want to know the procedure for R&R (remove and reinstall) of the engine camshaft. Your first step is to look in the index under the main heading of ENGINE until you find the entry "Camshaft." Now read to the right where under the column covering the tractor you are repairing, you will find a number which indicates the beginning paragraph pertaining to the camshaft. To locate this wanted paragraph in the manual, turn the pages until the running index appearing on the top outside corner of each page contains the number you are seeking. In this paragraph you will find the information concerning the removal of the camshaft.

SHOP MANUAL JOHN DEERE

MODEL 70 DIESEL

(General Purpose, Hi-Crop & Standard)

IDENTIFICATION

Tractor serial number stamped on plate on right side of main case
Serial No. 7017500 and Up

INDEX (By Starting Paragraph)

	Starting Engine	Tractor		Starting Engine	Tractor		Starting Engine	Tractor
BELT PULLEY		130	ENGINE CONT.			"POWR-TROL" CONT.		
BRAKES (Except Hi-Crop)		147	Oil pressure	54	94	Pressure test		166
BRAKES (Hi-Crop)		150	Oil pump	53	99	Pump		162
CARBURETOR	55	...	Piston pins	48	87	Remote cylinder		175
CLUTCH —Adjust	62	128	Pistons & rings	47	86	Rockshaft & cylinder		173
Overhaul	67	129	Piston & rod removal.....	46	85	Trouble shooting		161
COOLING SYSTEM			Oil seal (flywheel side)....	51	77	Valve housing		171
Fan & Shaft			Oil seal (belt pulley side)...	43	90A	PTO (Non-Continuous)		
(Manual Steering)		122	Rocker arms	42	75	Bevel gears		154
Fan & Shaft			Timing gear cover	43	...	Output shaft & seal.....		153
(Power Steering)		121	Timing gear housing	77		PTO (Continuous)		
Radiator		120	Timing gears	44	78	Adjust clutch		155
Thermostat		124	Valves & seats	37	72	Clutch overhaul		156
Water pump	58	125	Valve guides	38	73	Bevel gears		159
DIESEL FUEL SYSTEM			Valve springs	39	73	Oil pump		157
Filters & bleeding		102	Valve timing	41	76	Output shaft & seal.....		156
Injection nozzles		109	FINAL DRIVE (Except Hi-Crop)			REAR AXLE (Except Hi-Crop) ...		143
Injection pumps		105	Axle shafts		143	REAR AXLE (Hi-Crop)		144
Quick checks		101	Bull gears		143	STEERING (Manual)		
Transfer pump		103	Bull pinions		140	Adjustment		8
DIFFERENTIAL			FINAL DRIVE (Hi-Crop)			Overhaul		12
Overhaul		140	Axle shaft		144	Spindle & pedestal		15
Remove & reinstall		139	Bull gears		144	STEERING (Power)		
ENGINE			Bull pinions		140	Lubrication		16
Cam followers	40	84A	Drive chains		145	Operating pressure		18
Camshaft & bearings	45	84	Drive shaft		146	Pump		20
Connecting rods & bearings.	49	88	FRONT SYSTEM (Tricycle)		1	Spindle, pedestal & cylinder		31
Crankcase cover	93		"Roll-O-Matic"		2	Trouble shooting		17
Crankshaft	50	91	FRONT SYSTEM (Axle)			Valves		22
Cylinder block	89		Axle pivot pins		6	Worm & actuating sleeve..		27
Cylinder head	36	70	Drag links		5	TRANSMISSION (R & R and		
Cylinder sleeves	47	...	Steering knuckles		3	overhaul)	68	...
Engine removal	35	...	GOVERNOR —Adjust	57	114	Countershaft		138
Flywheel	52	92	Overhaul	44	115	Drive shaft		137
Ignition timing	60	...	HYDRAULIC "POWR-TROL"			Reduction gear cover		133
Injection timing	105	...	Bleeding & lubrication		160	Shifters & shafts		135
Main bearings	50	89A	Check valves		167	Sliding gear shaft		136
Oil filter		97	Operating valve		170	Top cover		134